
Kıckmaster

PortaGoal

Product No. M06027 **CONTENTS:**

- 1 Frame tube (x12)
- 2 Straight connector (x8)
- 3 Elbow connector (x4)
- 4 Bag (x1)
- 5 Netting (x2)
- 6 Tension strap (x2)
- 7 Securing peg (x16)
- 8 Ball (x1)



INFLATING THE BALL

Carefully insert the needle valve on the pump into the centre of the ball valve.

Slowly inflate the ball making sure you do not bend the needle valve.

When the ball is suitably inflated, slowly remove the pump and needle valve and store safely.

INFLATION PRESSURE: 2-4 PSI

NOTE: Do not over inflate the ball.



WARNINGS

To be assembled & dismantled by an adult.

To be used on a flat surface.

Check the frame assembly is securely located before use Ensure frame is securely pegged to ground before use.

Do not leave outdoors in adverse weather conditions.

Do not climb or hang from the structure.

Check regularly for wear and tear. discontinue use if any breakage is found. failure to do this may result in injury. Keep away from fire.

Keep away from heat sources.

THIS PRODUCT IS NOT SUITABLE FOR CHILDREN UNDER 3 YEARS DUE TO SMALL PARTS

Please retain this leaflet for reference to the manufacturer Carefully made in China to European Safety Standard











MV SPORTS & LEISURE LTD


35 Tameside Drive • Castle Bromwich Birmingham • B35 7AG • UK Email: info@mvsports.com www.mvsports.com

CUSTOMER HELPLINE


We make every effort to ensure that this product reaches you in satisfactory condition.


However if you have any queries, need assistance, or find this product defective, please call our Customer Helpline:


0870 8404255 (UK ONLY)




NOTE: If connector joints are tight, lubricate with washing up liquid.










(4) Place one end of the goal on a clean firm surface. Holding the top of the frame tubes, push downwards slowly, the frame tubes will bow, allowing you to push together the elbow connector, at the top of the goals.

Turn the goal over and repeat.







NOTE: To secure frame firmly to ground always anchor two pegs together (as shown) at anchor points indicated. Secure pegs using a mallet.

CAUTION: Check regularly that pegs are secure. Loose pegs may cause injury.

Care should be taken when using a mallet as misuse may cause injury.





CAUTION: When assembled the goal is under tension. Extreme care must be take when disassembling.

05.05 - ISSUE 3