

3+
YEARS

Tri-Scooter

This tri-scooter is to be assembled by an adult.

Check the contents and only remove the protective packaging from each item as and when it is to be fitted.

Please keep the packaging until you have completely assembled the scooter.




TOOLS

The tools you need are 13mm and 14mm spanner


CONTENTS:

- 1 Front wheel and fork assembly
- 2 Frame and footplate assembly
- 3 Handlebar assembly
- 4 Plastic washer (x2)
- 5 Plastic head bearing inserts (x2)
- 6 Clamp assembly
- 7 Clamp cover
- 8 Rear wheel (x2)
- 9 Axle bolt
- 10 Flat steel washer - small (x2)
- 11 Flat steel washer - large (x1)
- 12 Spring washer
- 13 Domed nut
- 14 Axle end cover (x2)
- 15 Plastic spacer (x2)




REAR WHEELS

- 1 Remove nut, spring washer, flat steel washers and plastic spacers from the axle bolt leaving the large flat steel washer on the axle bolt.
- 2 Insert axle bolt through first rear wheel and slide on a small flat steel washer and a plastic wheel spacer.
- 3 Insert axle through rear axle bearings.
- 4 Slide a plastic wheel spacer and a small flat steel washer onto axle bolt followed by second wheel.
- 5 Fit spring washer over threaded section of axle bolt and screw on domed nut.
- 6 Tighten nut using 14mm spanner.
- 7 Align the three spigots on the end covers with the holes in the central wheel flanges and push the covers firmly into position.



FRONT WHEEL AND HANDLEBARS


- 1 Push the 2 head bearing inserts firmly into the top and bottom of the head tube.
 - 2 Slide plastic washer onto front stem.
 - 3 Insert front fork stem through the frame head bearings with the slot in the stem facing rearwards
 - 4 Slide the second plastic washer and the clamp assembly onto the fork stem with clamping at the back
- NOTE: The top of the clamp assembly should be flush with the end of the fork stem. If not, check that the head bearing inserts are pushed fully into the head tube.**
- 5 Partly tighten the clamp until it nips the end of the fork stem.
 - 6 Slide the clamp cover onto the handlebar stem
 - 7 Insert the handlebar stem into the fork stem to the desired position, ensuring that the minimum insertion mark is not visible.
 - 8 Tighten the clamp bolt using a 13mm spanner and slide the clamp cover down over the clamp.



A GUIDE TO SAFE CYCLING & SCOOTERING

- 1 We recommend this scooter is for pavement use only.
 - 2 Do not ride at night. Visibility is often limited at dawn and dusk.
 - 3 Always give pedestrians right-of-way, and don't ride too close to them. Never park your bicycle or scooter where it can cause a nuisance.
 - 4 Avoid hazards that may cause you to lose control of you bicycle or scooter such as pot holes, uneven pavements and manhole covers.
 - 5 Leave plenty of room when passing parked vehicles and watch out for doors being opened in your path.
 - 6 Remember that braking distance should be increased in wet weather, and regular checks of brakes, steering and lighting should be made.
 - 7 Never carry passengers on your bicycle or scooter. Never carry packages in your hands while riding, or fix anything to your bicycle or scooter that could obstruct your visibility or control.
 - 8 Don't wear anything that restricts your hearing.
 - 9 Always ride with both hands on the handlebars.
 - 10 Don't wear very loose clothing, which could hang down and become caught in the wheels. Wear cuff bands or trouser clips to keep your trousers from getting caught in the chainwheel.
 - 11 We recommend that light-coloured or fluorescent clothing be worn which helps others to see you in daylight and poor light.
 - 12 Always wear proper safety equipment. We recommend a helmet, long-sleeved shirt, long trousers, shoes, elbow pads and knee pads. Gloves and eye protection also make good sense. Cover your handlebars, stem and top tube with safety pads for extra protection.
 - 13 Don't ride your bicycle if the chain cover is not attached
- Please refer to the Highway Code regarding rules for cyclists

ASSEMBLED SCOOTER



SAFETY FIRST

Please check all fixings are secure before handing to a child.

This toy should be used with caution, since it requires great skill, so as to avoid falls or collisions causing injury to the user and third parties.

FOR YOUR CHILD'S SAFETY

Recheck that all screws, nuts and bolts are firmly tightened. Make sure that your child is capable of riding this tri-scooter. Do not allow your child to ride without supervision.

Please check regularly that everything is securely tightened, especially the handlebars and wheel axle nuts. Also check that the grips have not deteriorated. Failure to carry out these maintenance and checks, could lead to component failure and consequently to a possible accident.

WARNING: Protective equipment should be worn. Not for children with a body weight of more than 20kg

Not suitable for children under 36 months due to small parts.

Please retain this leaflet for reference to the manufacturer. Carefully made in China to European Safety Standards.

CE This mark denotes compliance with the standards laid down by the EC (European Community).

CUSTOMER HELPLINE

We make every effort to ensure that this product reaches you in satisfactory condition. However if you have any queries, need assistance, or find this product defective, please call our Customer Helpline:

0870 8404255 (UK ONLY)

DISTRIBUTED BY



MV SPORTS & LEISURE LTD

35 Tameside Drive • Castle Bromwich • Birmingham • B35 7AG • UK
Email: info@mvsports.co.uk